

MAINTENANCE:

Your COUNT-100 / COUNT-200 requires no maintenance.

Product Limited Warranty

All Labelmate Products are warranted to the original end-user customer to be free from defects in materials and workmanship. If it is determined by Labelmate that a product has failed under the terms of this warranty, the product will be repaired or replaced at no charge to the customer. Labelmate reserves all rights to determination of coverage and liability under this warranty. The warranty period for all new Labelmate products is outlined below:

Warranty Period	Products Covered
5 years	Label Rewinders Label Unwinders
3 years	Label Counters (mechanical parts only) Label Slitters (mechanical parts only) Label Dispensers Printer Mechanisms
1 year	Power Supply Modules Counter modules Encoders Any products not specified above.

The warranty period for all products starts on the date purchased by the original end-user customer. Warranty coverage is not transferable with ownership and will terminate immediately upon rental, resale or any other change in ownership. This warranty does not cover repair to any product which is damaged, has been modified, is missing parts, or has been opened or repaired by any unauthorised person. Use of any unauthorised accessory or attachment will void coverage. Purchase documentation should be retained for coverage verification.

In the event your product requires service, please contact the distributor you bought the product from. The customer assumes responsibility for all cost and risk incurred in transport for service.

Labelmate makes no other warranty of any kind expressed or implied, or to suitability or fitness for a particular purpose. No other person, agent or reseller is authorised to give any warranties on behalf of Labelmate. Any obligation to warranty other than that specifically addressed above is hereby disclaimed.

LABELMATE LLC

69 AVENUE ALPHONSE XIII, 1180 BRUSSELS, BELGIUM

TEL: +322.375.69.60 – FAX: +322.375.38.96


brussels@labelmate.com

www.labelmateeurope.com

COUNT-100 / COUNT-200

Label Counter for use with CAT-3 Label Rewinders

- ***Digital Circuitry for Accuracy and Repeatability.***
- ***Pre-set Counter.***
- ***Stops Rewinder when Count is reached.***



Remove all parts from the shipping container and verify contents.

PACKAGE CONTENTS:

- *User Manual (this document)*
- *COUNT-100 or COUNT-200 Counter Unit*
- *Power Supply Module*

Retain the Shipping Container and Packaging for Storage and Transport

SPECIFICATIONS:

Weight of the machine: COUNT-100: 7,42Kg – COUNT-200: 8,13Kg.

Max. Label Roll Width: C-100: 170mm (6.7") – C-200: 255mm (10").

Power Supply: Input: 220-240VAC – 50-60Hz. Output: 12VDC



WARNING!
This Product is for indoor use only.
Not for use in wet locations.

IMPORTANT INFORMATION:

- This product is a label counter. It is only to be used to count labels of the recommended dimensions in an indoor, dry environment.
- The machine has to be unplugged before any manipulation.
- The machine is to be used on a flat surface, if the surface is not flat; it is to be fixed using the holes in the base plate.
- Do not leave the power cable in a passageway.
- The ambient light of the working area needs to be sufficient to avoid any risk.
- The counter can be used in ambient temperatures of +2°C to 40°C.
- Connection of the machine to the power source must respect local and European legislations.

PC-1 PRE-SET COUNTER SET-UP:

1. Verify that the AC/DC Adaptor "VOLT CHANGE SW." is set to "12" and plug it into a suitable AC Power Outlet. Plug the Cord on the AC/DC Adaptor into the Power Input Jack on the bottom of the Counter Display Module.
2. Plug the Control Cable (with 3.5mm plugs at each end) between the Output Jack on the bottom of the Counter Display Module and the "EXTERNAL HALT CONTROL" jack on the CAT-2 Label Rewinder.
3. The Counter is pre-programmed as a Preset Count-up Counter. Press each of the 6-digits for the count desired. This is the number of labels you wish to pass through the Label Sensor before the Counter issues a "HALT" command to the CAT-2 Label Rewinder.
4. Pull a short strip of labels back and forth through the Label Sensor Gap and observe the count on the Counter increasing. When the preset number of labels is reached, the PC-1 Counter will issue a Halt Command for the CAT-2 Label Rewinder to stop. Pressing "RESET" will reset the count and restart the CAT-2.
5. See the included detailed manual for the Pre-set Counter itself for other Counter options.



FOR YOUR SAFETY:
Switch off device before any manipulation.

COUNTER USE:

1. Place the COUNT-100 or COUNT-200 Label Counter so that it is perpendicular to the label web.
2. Observe the Paper Path Label on the Counter: Feed the label web under the metal Rotating Paper Guide and over the Nylon Fixed Paper Guide.
3. Adjust the position of the rings on the Rotating and Fixed Paper Guides to the width of your label web. Only finger tighten the screws. The labels must pass through the black sensor slot between the round Paper Guides.
4. Affix the label web to the label rewind core on the Label Rewinder.
5. The Counter will count the number of labels passing through the sensor air gap.

NOTE: If you observe erratic counting, clean the Optical Sensor with isopropyl alcohol.

INTERNAL CIRCUIT PROTECTION:

The COUNT-100 and COUNT-200 Label Counters have an internal device for circuit protection. There are no user serviceable parts inside. In the event of operational problems, please contact LABELMATE for assistance.